



STANDARD 4'-0" x 4'-0" CORNER:

1. ATTACH TOP RAIL AND MID RAIL TO ONE END POST. HAND TIGHTEN SETSCREWS.
2. ATTACH CORNER POST TO PRE ASSEMBLED TOP RAIL AND MID RAIL. HAND TIGHTEN SETSCREWS.
3. ATTACH OTHER TOP RAIL AND MID RAIL TO CORNER POST. HAND TIGHTEN SETSCREWS.
4. ATTACH OTHER END POST TO TOP RAIL AND MID RAIL. HAND TIGHTEN SETSCREWS.
5. LOCATE RAIL ASSEMBLY AND ANCHOR INTO POSITION. ANCHORS NOT PROVIDED.
6. USING A LEVEL, CHECK THAT POST ARE VERTICAL AND RAILS ARE LEVEL.
7. TIGHTEN ALL SETSCREWS.

THIS DRAWING AND ALL THE INFORMATION THEREON IS THE PROPERTY OF THE HOLLAENDER MFG. CO., IS CONFIDENTIAL AND MUST NOT BE MADE PUBLIC, NOR COPIED, NOR USED, TO THE DISADVANTAGE OF SAID HOLLAENDER MFG. CO. AND IS SUBJECT TO RETURN ON DEMAND.
 COPYRIGHT 2013.
 HOLLAENDER - MANUFACTURING CO.

NO.	REVISIONS	DATE	APPROVED
0	RELEASED FOR APPROVAL	1-15-13	BW

Hollaender[®]
 STRUCTURAL ENGINEERING GROUP
 10285 WAYNE AVENUE
 CINCINNATI, OH 45215-6399
 PHONE: (800) 772-8800 FAX: (502) 772-8806
 WWW.HOLLAENDER.COM

PROJECT	CUSTOMER	DESCRIPTION
CORNER RAIL SECTION 4'-0" c/c POST 42" HIGH RAIL		MODULAR RAIL SECTION DRAWINGS

DESIGN BY	APPROVED BY	DATE
GG	BW	1-15-12
50150		NTS
MILL		7066-S
ALUM. PIPE/ALUM FITTING		1 of 1

